



CTP Valve Guides

CTP Valve Guides -

CTP Valve Guides provide high wear resistance and are built with the same precision standards you have come to expect from all CTP parts.

Engine Model/ Application	Part No.	Description
342	1W1816	GUIDE VALVE
1674	5S2921	GUIDE VALVE
3046	1039247	GUIDE VALVE
3054	1605436	GUIDE-INTAKE
3054	1605438	GUIDE-EXHAUST
3208	6I2864	GUIDE-INTAKE
3208	6I2865	GUIDE-EXHAUST
3306	1621589	GUIDE VALVE
3306	3N0515	GUIDE VALVE
3412	2137536	GUIDE-INTAKE
3412	2137537	GUIDE-EXHAUST
3516	1845494	GUIDE VALVE
3516	1845495	GUIDE VALVE

Engine Model/ Application	Part No.	Description
3056, 3054	1639256	GUIDE-EXHAUST
3056, 3054	1850882	GUIDE-INTAKE
3114, 3116	9Y8848	GUIDE VALVE
3126B/E	1409670	GUIDE VALVE
3126E	1478220	GUIDE VALVE
312C & 312C L/3064	1838172	GUIDE VALVE
312C & 312C L/3064	1838173	GUIDE VALVE
313B	0947749	GUIDE VALVE
3176, C10	1008150	GUIDE VALVE
3306, G3306	9Y7895	GUIDE VALVE
3306C	1487425	GUIDE VALVE
3406, 3408, 3412	1737188	GUIDE VALVE
3406C	1227374	GUIDE VALVE

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions.
Part Numbers are used for reference purposes only

CTP Valve Guides -

Engine Model/ Application	Part No.	Description
3406E, C15	1227375	GUIDE VALVE
3508, 3512, 3516	1339306	GUIDE-INTAKE
3508, 3512, 3516	1976995	GUIDE-EXHAUST
C13	2682953	GUIDE VALVE
C9	2595829	GUIDE VALVE
C9	2604856	GUIDE VALVE
D-336, 1676	1S2899	GUIDE VALVE
D318, D4, D315	4F6949	GUIDE VALVE
D330/D333	4N3668	GUIDE VALVE
D343, D346, D348	6N2236	GUIDE VALVE
D379, D398, D399	2N9298	GUIDE INTAKE
D379, D398, D399	2N9299	GUIDE-EXHAUST
D379, D398, D399	7C3720	GUIDE VALVE IN 0.005" OS
D7, D8, D8H	7N2051	GUIDE VALVE
D8, D342	2S0893	GUIDE VALVE
D8H	6N8847	GUIDE-EXHAUST
D9, D9G, D9H	4N3664	GUIDE-INTAKE
G3300	4W9176	GUIDE VALVE
G3306	7E1551	GUIDE VALVE
G3400	1511330	GUIDE-VALVE
G3406	1516235	GUIDE-EXHAUST
G3408	7W1636	GUIDE VALVE
G3508, G3512, G3516	9Y1846	GUIDE-EXHAUST
G3508, G3512, G3516	9Y1847	GUIDE VALVE
G3516	1916766	GUIDE-INTAKE
G3516	2550897	GUIDE-EXHAUST
G3516B	2061541	GUIDE-EXHAUST
N/A	2592186	GUIDE VALVE
N/A	4H0621	GUIDE VALVE
N/A	7C0363	GUIDE VALVE

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions.

Part Numbers are used for reference purposes only