

CTP Gas Springs facilitate the opening and closing of doors, windows and hoods of machines or trucks. They can easily execute lifting or lowering tasks, and are useful to control the pressure of opening and closing heavy lid objects. To make your life simpler, CTP guarantees quality Gas Springs so you can peacefully execute your job with absolutely no concerns.

CTP Gas Springs -

Part No.	Use	Machine Model
1148861	Hood GP Engine	416D, 442D, 428D, 420D, 436C
1429287	Armrest	216B, 232B2, 242B2, 259B3, 247B3
1594269	Door GP-Cab	420E, 450E, 416E, 428E, 428F
8T7041	Cabine Door	R2900G, R1600G, R1700G, R3000H, 446B, 924F

Other Gas Springs also Available:

Part No.	Use	Machine Model	
1219748	Window GP - Cab	428C, 416C, 436C, 426C	
1225762	Cabine GP	M318, M315, M312, M320	
1439434	Hood & Guard GP	924G & 924Gz, 988F	
1439435	Hood & Guard GP	988F	
1572193	Window GP - Cab	303.5, 304.5, 302.5, 301.5	
2102518	Door GP-Hood	IT28G, 928G	
2102519	Door GP-Hood	IT28G, 928G	
2287696	Hood & Guard GP	928 USAF10K ATFL, 924H & 924Hz, 924G & 924Gz, 930G	
3199510	Steering Column	IT28G, 938, 938H, 914G, 924H	



^{*} Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only.